

POTS AND PANS

Dish Detergent

POTS AND PANS Premium Dishwashing Detergent is a concentrated, heavy duty, high foaming, hard working detergent for manual cleaning of dishes, silverware, serving dishes, glassware, and, of course, pots and pans. POTS AND PANS is a blend of highly effective, biodegradable synthetic detergents and a non-phosphorus chelate that penetrates, softens, and removes dried-on and burnt-on food soils and rinses freely and spot free. POTS AND PANS is mild to hands, concentrated and economical. So, "get out of that kitchen" - use POTS AND PANS.

Place appropriate amount (see recommendations below) of POTS AND PANS in sink and fill with a strong stream of water to create suds. Soak or scrub to achieve desired results.

For dishes, silverware, and glasses:

Use 1/2 to 3 ounces per gallon of water for light to heavily soiled dishes.

For heavily-soiled pots and pans:

Add 3/4 to 4 ounces per gallon of water.

SPECIFICATIONS FOR POTS AND PANS

Appearance pH	Clear, green liquid 8.5 ±.5
Specific Gravity	
Flash Point	None
Dilution	
Foam	
Hardwater Tolerance	
Ammonia	
Butyl	
Phosphate	
Storage Stability	Excellent, 2 Years Minimum
USDA Registered ?	No

